
Create an RDS Database Instance


Step 1: Creating the RDS Database instance

1.1 Go to the AWS console and select AWS services. In the search tab, search for RDS



1.2 To create MySQL DB, set the following configurations:


Under Choose a database creation method, select Standard Create




Engine Type: MySQL

Edition: MySQL Community


Version: Select the latest – MySQL 8.0.19 (make sure it matches with local system MySQL version)




1.3 Specify DB Details and provide DB Instance, username and password for your DB Instance before clicking on **Next**



1.4 Under **Connective**, select the default VPC. In the advance settings



- 1.4.1 Set subnet group to **default**
- 1.4.2 Enable Public accessibility
- 1.4.3 Under VPC security group, select **Create new**
- 1.4.4 Set database port to **3306**




1.5 Under **Additional configuration**, configure the following details:

Initial database name

DB parameter group

Set the backup period to 7 days



1.6 Keep all other options as default before launching DB instance